

SAFE WORK METHOD STATEMENT

BNP SWMS 04 - CanyonTone V2

Issued 15-May-23

ABN: 69 056 378 575	ACN: 056 378 575	,	11 Huntington Place, Banyo	QLD 4014	PH: (07) 3630 2500
Project				Project No	
Client			Location		
Person in control of works			Contact Number		
Work Activity	Installation and painting of Canyon	Tone			
High Risk Construction Activities	 ☐ Risk of a person falling more than 2 met ☐ Work on or near pressurised gas mains piping ☐ Work in an area with movement of power mobile plant 	or	in or near a confined space on or near energised electri ns or services in or near water or other liq a risk of drowning	1.5 m or a tun ical □ Work on, ii shipping lane traffic other th uid that □ Is carried of	near a shaft or trench deeper than nnel n or adjacent to a road, railway, or other traffic corridor in use by nan pedestrians out in an area that may have a or flammable atmosphere
Consultation in	Name	Position		Signature	Date
development of SWMS	Greg Steele	Director		Stale	
	Randal Black	National Mana	ager	3	
	Brendan Evans	QLD Manager	ſ	yer	
Approved by	Randal Black Positi	ion National	Manager Signatu	re	Date
Legislation and Codes of Practice	Work Health & Safety Act 2011, Work Health and Safety Consultation, Co-ope Traffic Management for Construction of Managing the Risks of Hazardous Cherlant Code of Practice 2021, Abrasive	eration and Co-or Maintenance Wo micals Code of Pi	dination 2011 ork Code of Practice 200 ractice 2021, Hazardous	8, MUTCD Part 3 Manual Tasks Code of Pra	actice 2021, Managing Risks of
Plant and Equipment	Mixer, air compressor, linemarking		•		
required	Elevated Working Platform up to 10	.5metres, scisso	or lift		
Inspections and maintenance	Preoperational check to be conduct	ed on plant			
Materials used	CanyonTone				



SAFE WORK METHOD STATEMENT

BNP SWMS 04 - CanyonTone V2

Issued 15-May-23

ABN: 69 056 378 575		ACN: 056 378 575 11 Huntington Place, Banyo QLD 4014 PH: (07) 3630 2500						
Specific Training		General industry induction (QLD white card); Site specific induction, trained in SWMS / SDS procedures, Trained in Safe & Proper Use of PPE						
	Elev	rated Working Platform up to 10	5.5metres, scissor lift					
Personal Protective Equipment								

Implement, Monito	mplement, Monitor and Review							
Actions before work commences	Workers will be inducted onto the Safe Work Method Statement Traffic management controls, approved plans and permits must be in place before working within 6mtrs of live traffic. All traffic controllers must hold the relevant qualification for the role. Evidence must be sighted prior to start of works. Works must be planned and structured to cause minimum disruption to local traffic, pedestrians and residents. Conduct pre-operational checks on plant							
Actions during works	Signage checks must be completed at regular intervals and documented throughout the day. Works will be monitored to ensure works are carried out in accordance with the Safe Work Method Statement Report any hazards or incidents. Person in control of the works is the nominated person who will ensure the implementation of this SWMS. All incidents and / or near misses must be reported following the Brick N Pave incident reporting process.							
Actions after work is completed	Safe Work Method Statement will be reviewed and amended when changes are made or where a new hazard has been identified, or at least annually							

Risk Assessment

	HEALTH & SAFETY CONSEQUENCES	1. INSIGNIFICANT - no injuries	MINOR first aid treatment, spillage contained on site	3. MODERATE - medical treatment, spillage contained with outside help	4. MAJOR - extensive injuries, loss of production	5. CATASTROPHIC - death, toxic release of chemicals	HIGHEST Level 1 Eliminate the hazards
>	A. Common or Frequent Occurrence	M5	M10	H15	E20	E25	Level 2 Substitute the hazard with something safer Isolate the hazard from people
늘	B. Is known to Occur or 'It Has Happened"	L4	M8	H12	E16	E20	Reduce the risks through engineering controls
BAB	C. Could Occur or "I've Heard of it Happening"	L3	M6	M9	H12	H15	Seliability of Penel 3
RO	D. Not Likely to Occur	L2	L4	М6	M8	M10	Reduce exposure to the hazard using administrative actions
Ь	E. Practically Impossible	L1	L2	L3	L4	M5	LOWEST Use personal protective equipment LEAST

Emerc	iencv	Proced	ures
	, ,		

EWP gets stuck on	Stop operation of EWP immediately
structure	Assess potential damage
	Foreman to authorise reversing EWP from structure
	Assess damage to EWP
	 If worker unable to operates EWP, competent person can operate EWP from ground
	Ensure area is clear before moving EWP
	Ensure structure is stabilised before EWP is moved
	EWP to be assessed by a competent person for structural damage
	Follow up with prescribed incident management
EWP stuck elevated	Notify Foreman
Personnel unable to	Assess situation
operate EWP from Platform	Ensure area is clear
	Engage manual release to lower EWP
	Follow up with prescribed incident management

Item	Job sequence	Potential Hazards	Risk	Risk L x C = R	Control Measures	Residual Risk L x C = R	Responsible Person
1.	Site Establishment of works on, in or adjacent to a road or traffic corridor in use by traffic other than pedestrians	Public	Incident due to proximity to adjacent road	B x 5 = E20	BNP to hire a licensed Traffic Management Company to develop and establish appropriate traffic management controls taking in consideration sequencing, job specific Temporary Road Closure Approval requirements and scheduling of works.	D x 5 = M10	BNP representative Traffic Management Company
					Ensure permits are current.		
					Traffic Management Plan and Traffic Guidance Schemes to be developed and implemented by a licenced traffic management company.		
					Ensure traffic management controls are inspected and signed off by traffic management company.		
					Site vehicles to have warning devices (e.g. flashing lights, vehicle signage, etc.).		
					Workers to wear high visibility clothing (night vis as required).		
2.	Starting Work	Poor consultation	Incident due to poor	B x 5 = E20	BNP to coordinate consultation between site personnel and traffic control company.	D x 5 = M10	BNP representative
			consultation	Consultation to include	Consultation to include		,
					 Scheduling of works Movement of plant and vehicles Nominated UHF channel Specific hazards and controls relevant to the shift Emergency response 		
3.	Unloading plant	Falls	Injury due to fall	B x 4 = E16	Ensure fall protection is in place on truck. Utilise ladder access to rear of truck.	D x 4 = M8	BNP representative

Item	Job sequence	Potential Hazards	Risk	Risk L x C = R	Control Measures	Residual Risk L x C = R	Responsible Person
4.		Manual Tasks	Sprains and strains	B x 3 = H12	Use mechanical assistance to lift heavy plant for truck.	D x 3 = M6	BNP representative
					Ensure personnel understand what manual handling is not just about the weight e.g. for example, twisting, jerking or reaching, doing the task too fast, using too much force or lifting the wrong way.		Site personnel
					If mechanical assistance is not reasonable, utilise team lifts.		
5.	Working at heights	Plant stability	Rollover	B x 4 = E16	Ground condition to be assessed including	D x 4 = M8	BNP
	Elevated working platform	Proximity to others	Contact with personnel		Access to work area andSet up at work area		representative Site personnel
					Pad size under outriggers may be calculated from the Mobile Crane Code of Practice.		
					Avoid working near drop-offs, holes, unstable or slippery surfaces and other possible hazardous conditions.		
6.		Operator	Incident due to	B x 4 = E16	Ensure operator competency including	D x 4 = M8	BNP
		Competency Plant Failure	lack of competency or plant failure		 High risk work license (if over 11m boom) or Formal competency 		representative Site personnel
					Operator to conduct a pre-operational check daily and ensure that the maintenance records are current.		

Item	Job sequence	Potential Hazards	Risk	Risk L x C = R	Control Measures	Residual Risk L x C = R	Responsible Person
7.		Small tools / proximity to	Falling objects / crush incidents/	B x 4 = E16	Ensure exclusion zone is established around working EWP	D x 4 = M8	BNP representative
		structures / sudden movement	worker projected from basket		Personnel must wear a harness in a fall restraint mode attached to anchor provided in platform (knuckle boom type plant).		Site personnel
					Conduct visual inspection of harness e.g. look for damage, material spilt on webbing etc. and ensure a competent person has inspected the harness within the last 6months.		
					Close the entry gate before operating.		
					Be aware of limited sight distance and blind spots when driving or operating		
					Be aware of extended platform position when moving the machine		
					Check work area for overhead obstructions or other possible hazards		
					Be aware of crushing hazard when grasping the platform guard rail		
					Personnel must always wear safety helmets.		
					Do not lower the platform unless the area below is clear of personnel and obstructions.		
8.	Mixing product	Chemical	Contact with CanyonTone	B x 4 = E16	Operator to conduct preoperational checks on plant.	D x 4 = M8	BNP representative
					Major defects are to be reported to the BNP representative.		Site personnel
					Wear respiratory protection when mixing dry product.		
					Be aware of other workers and proximity to traffic.		

Item	Job sequence	Potential Hazards	Risk	Risk L x C = R	Control Measures	Residual Risk L x C = R	Responsible Person
9.	Application	Overspray	Contact with workers	B x 3 = H12	Determine whether wind conditions may affect other workers or adjacent traffic. Work is not to distract adjacent traffic. Conduct a couple of test runs to determine suitability of exclusion zones / direction of work. Supervisor to monitor progress of works and any change.	D x 3 = M6	BNP representative Site personnel
10.	General site hazards	Fuelling Plant	Contact with fuel Fire	B x 3 = H12	Ensure correct fuel is used. Ensure spill kit and ABE fire extinguisher is available. Ensure no naked flames are in the fuelling area.	D x 3 = M6	BNP representative Site personnel
11.		Noise	Exposure to excessive noise Hearing Damage	C x 4 = H12	Assess work area for excessive noise. Generally, if there is a need to shout due to production noise, controls need to be implemented. When deciding control measure, the hierarchy of control must be considered, and the highest reasonably practicable control measure must be used e.g. remove personnel away from the noise rather than PPE.	D x 4 = M8	BNP representative Site personnel
12.		Dust	Inhalation of airborne contaminants	B x 3 = H12	Work activities that produced to be monitored and where possible dust should be controlled by engineering controls such as water suppression or extraction If dust cannot be controlled that ensure workers are protected by suitable respiratory protection. Ensure other workers are removed from the immediate area.	D x 3 = M6	BNP representative Site personnel

Item	Job sequence	Potential Hazards	Risk	Risk L x C = R	Control Measures	Residual Risk L x C = R	Responsible Person
13.		Working outdoors	Heat Stress Skin Cancer	B x 3 = H12	Personnel to be aware of the signs and symptom of heat illness and provided advice on how to minimise the risk including • Keep hydrated, about 250ml per 30minutes • Monitor yourself • Check in with your mate • Avoid alcohol and caffeine Signs and symptoms of heat stress include • Pale clammy or hot flushed dry skin • Headaches • Nausea and/or vomiting Personnel to be protected from the risk of sun damage. PPE requirements include sunscreen, brims, sunglasses, longs sleeves and long pants. Personnel to report any symptoms of heat illness to BNP representative immediately. Personnel to receive first aid and medical attention. BNP representative to promote heat illness prevention during daily prestart meeting and toolbox meetings.	D x 3 = M6	BNP representative Site personnel

Item	Job sequence	Potential Hazards	Risk	Risk L x C = R	Control Measures	Residual Risk L x C = R	Responsible Person
14.	Finalise Works	Equipment left on road Traffic signage not removed / reinstalled	Incident due to contact with equipment Inappropriate	B x 4 = E16	BNP representative to inspect closed work area to ensure all equipment is accounted for and packed onto the site vehicles. Liaise with traffic management company before	D x 4 = M8	BNP representative Traffic Management
	Terrioved / Terristaned		signage		opening work area.		Company
					Traffic Management company to establish normal traffic conditions.		
			BNP representation to conduct a final inspection to ensure				
					No equipment has been missedAll temporary signage has been removed		
					All cover traffic signage has been restored		

Add	Iditional Hazards and Control Measures						
Item	Work Activity	What can go wrong	What will be put in place	Responsible Person			
1.							
2.							
3.							
4.							
5.							

Name	Signature	Date	Name	Signature	Date			
the undersigned,	confirm that the SWMS nomi	nated above has	been explained and it	s contents are clearly underst	ood and accepted			
confirm that requ	ired qualifications to underta	ke the activity are	current. I clearly und	derstand the controls in this S	WMS must be			
				d with the Personnel Protective	e Equipment			
identified, consulted and given the opportunity to comment on this SWMS.								